

## Instruction Manual

Manuel d'instructions

FR

Manual de instrucciones

ES




\* 4 5 7 3 9 4 8 2 1 \* (1)

©2015 Sony Corporation Printed in Malaysia

NW-A25/A25HN/A26HN/A27HN

English

### About the manuals

1. Instruction Manual (this manual)
2.  (Startup Guide)

The Startup Guide describes the following:

- Basic operating instructions of your WALKMAN®
- How to access the “Help Guide”, which contains all of the operating instructions and explanations of customer support websites, etc.
- How to access useful PC applications websites on the internet

While browsing is free, you may be charged a communication fee according to your carrier contract.

Depending on the country/region in which you have purchased your Walkman, some models may not be available.

## Notes for using Walkman


### Note for battery

- To prevent battery deterioration, charge the battery at least once every six months or every year.


### Bluetooth capabilities

You can listen to music stored on your Walkman from Bluetooth audio devices such as headphones or speakers.


#### Pairing (first time the device is used)

1. Set the Bluetooth audio device to pairing mode. (Refer to the device’s instruction manual.)
2. From the Home menu of your Walkman, select  [Bluetooth] - [Add Device (Pairing)] - the Bluetooth audio device to pair with. After pairing is completed, the Bluetooth connection is made automatically.

#### Connecting (subsequent uses)

1. Turn on the paired Bluetooth audio device and set it to standby.
2. From the Home menu of your Walkman, select  [Bluetooth] - [Connect to Audio Device] - the paired Bluetooth audio device to connect with.

#### Disconnecting

From the Home menu of your Walkman, select  [Bluetooth] - [Disconnect Audio Device].

## Symptom & Remedy

### Your Walkman cannot charge the battery or is not recognized on your computer.

- The USB cable (supplied) is not connected to a USB connector on your computer properly. Disconnect the USB cable, and then reconnect it.
- When you use your Walkman for the first time, or if you have not used the Walkman for a long time, it may take a few minutes to be recognized by the computer. Check that the computer recognizes the Walkman after you have connected it to the computer for about 10 minutes.

### The computer does not recognize a microSD card inserted in your Walkman.

- After inserting a microSD card into your Walkman, connect it to your computer and switch the storage by following the instructions displayed on the Walkman.

## Compliance & Information

### Information on laws and trademarks

For information on laws, regulations and trademark rights, refer to “Important Information” contained in the supplied software. To read it, install the supplied software on your computer.

To install it, open [WALKMAN] in your Walkman’s system storage after connecting to your computer.

Windows user: [FOR\_WINDOWS] - [Help\_Guide\_Installer(.exe)]

Mac user: [FOR\_MAC] - [Help\_Guide\_Installer\_for\_mac]

After installing the software, double-click the shortcut or the alias icon generated on your desktop.

### About the in-ear headphones

The earbuds seal your ears. Therefore, be aware that there is a risk of damage to your ears or eardrums if strong pressure is applied to the earbuds or the earbuds are suddenly removed from your ears. After use, be sure to take the earbuds off your ears gently.

### About the headphones

- Avoid playing the unit at so loud a volume that extended play might affect your hearing.
- At a high volume outside sounds may become inaudible. Avoid listening to the unit in situations where hearing must not be impaired, for example, while driving or cycling.
- As the headphones are of open-air design, sounds go out through the headphones. Remember not to disturb those close to you.

### Owner’s Record

The model and serial numbers are located on the back of the player. Record them in the space provided below. Refer to these numbers in the spaces whenever you call upon your Sony dealer regarding this product.


Model No. \_\_\_\_\_

Serial No. \_\_\_\_\_

Design and specifications are subject to change without notice.

Français

### À propos des manuels

1. Manuel d'instructions (ce manuel)
2.  (Guide de démarrage)

Le Guide de démarrage comprend les éléments ci-dessous :

- Instructions d’utilisation basiques de votre WALKMAN®
- Comment accéder au « Guide d’aide », qui contient le mode d’emploi et les explications sur les sites web d’assistance clientèle, etc.
- Comment accéder aux sites web d’applications PC utiles sur internet

Bien que la navigation soit gratuite, des frais de communication peuvent vous être facturés par votre opérateur.

Selon le pays ou la région où vous avez acheté votre Walkman, il se peut que certains modèles ne soient pas disponibles.

## Notes concernant l’utilisation du Walkman


### Note concernant la batterie

- Pour éviter toute détérioration de la batterie, chargez-la au moins une fois tous les six mois ou chaque année.


### Fonctionnalités Bluetooth

Vous pouvez écouter la musique stockée sur votre Walkman à partir de périphériques audio Bluetooth tels que des écouteurs ou des enceintes.


#### Pairage (lors de la première utilisation du périphérique)

1. Réglez le périphérique audio Bluetooth sur le mode pairage. (Reportez-vous au manuel d’instructions du périphérique.)
2. Dans le menu Accueil de votre Walkman, sélectionnez  [Bluetooth] - [Ajouter périph. (Pairage)] - périphérique audio Bluetooth avec lequel effectuer le pairage. Lorsque le pairage est terminé, la connexion Bluetooth s’effectue automatiquement.

#### Connexion (utilisations ultérieures)

1. Mettez le périphérique audio Bluetooth apparié sous tension et réglez-le sur veille.
2. Dans le menu Accueil de votre Walkman, sélectionnez  [Bluetooth] - [Connecter au périph. audio] - périphérique audio Bluetooth avec lequel se connecter.

#### Déconnexion

Dans le menu Accueil de votre Walkman, sélectionnez  [Bluetooth] - [Déconnecter périph. audio].

## Symptôme et remède

### Votre Walkman ne peut pas charger la batterie ou n’est pas reconnu sur votre ordinateur.

- Le câble USB (fourni) n’est pas connecté correctement à un connecteur USB sur votre ordinateur. Déconnectez le câble USB, puis reconnectez-le.
- Si vous utilisez votre Walkman pour la première fois, ou si vous n’avez pas utilisé votre Walkman pendant une période prolongée, il peut s’écouler quelques minutes avant que l’ordinateur ne le reconnaisse. Vérifiez que l’ordinateur reconnaît le Walkman une fois qu’il est raccordé à l’ordinateur depuis environ 10 minutes.

### L’ordinateur ne reconnaît pas une carte microSD insérée dans votre Walkman.

- Après avoir inséré une carte microSD dans votre Walkman, connectez-le à votre ordinateur et basculez le stockage en suivant les instructions affichées sur le Walkman.

## Conformité et informations

### Informations relatives aux lois et aux marques commerciales

Pour obtenir des informations sur la législation, les réglementations et les droits relatifs aux marques commerciales, reportez-vous à la rubrique « Informations importantes » qui accompagne le logiciel fourni. Afin de pouvoir la lire, vous devez installer le logiciel fourni sur votre ordinateur.

Pour l’installer, ouvrez [WALKMAN] dans le système de stockage de votre Walkman après la connexion à votre ordinateur.

Utilisateur Windows : [FOR\_WINDOWS] - [Help\_Guide\_Installer(.exe)]

Utilisateur Mac : [FOR\_MAC] - [Help\_Guide\_Installer\_for\_mac]

Après avoir installé le logiciel, double-cliquez sur le raccourci ou sur l’icône d’alias générée sur votre ordinateur.

### À propos des écouteurs intra-auriculaires

Les oreillettes épousent vous oreilles. Par conséquent, soyez conscient qu’il existe un risque de dommage pour les oreilles ou les membranes des tympanes si vous appliquez une pression trop importante sur les oreillettes ou si vous retirez brusquement les oreillettes des oreilles. Après utilisation, veillez à retirer délicatement des oreillettes de vos oreilles.

### Remarque sur les écouteurs

- Eviter de faire fonctionner l’appareil à un niveau sonore tel qu’il serait préjudiciable à votre sens de l’ouïe.
- A volume élevé, les sons en provenance de l’extérieur peuvent être inaudibles. Eviter d’écouter avec cet appareil dans des situations où le sens de l’ouïe ne doit pas être altéré, en voiture ou à bicyclette par exemple.
- Comme les écouteurs sont de type ouvert, les sons sont audibles de l’extérieur. Veillez à ne pas déranger votre entourage.

La conception et les spécifications peuvent faire l’objet de modifications sans préavis.

