

Digital Still Camera

Appareil photo numérique

Cámara fotografía digital


Reference Guide

Guide de référence






























































Guía de referencia

Cyber-shot

DSC-QX30



©2014 Sony Corporation Printed in China


^[1]

